



KONICA MINOLTA



NEW Spectrophotometer

CM-26dG

CM-26d

CM-25d



Advanced performance
for the times.

Ease of use
for front-line use.

Highest level of repeatability with high inter-instrument agreement, incomparable speed, and high usability.

The CM-26dG Series from Konica Minolta offers three variations of advanced portable spectrophotometers.

The high-end CM-26dG and CM-26d models bring the industry's highest level of accuracy, with the CM-26dG capable of simultaneously measuring color and gloss, and the CM-26d specifically for measuring color.


The lineup is rounded out with the high cost-performance model, the CM-25d.

NEW Spectrophotometer
CM-26dG | **CM-26d** | **CM-25d**




2-in-1 instrument for measuring color and gloss

The CM-26dG performs the job of two instruments by simultaneously measuring color and gloss. Because color and gloss measurements can be done with a single device, separate spectrophotometers and glossmeters do not need to be prepared and switched in and out, which instantly improves work efficiency especially when measuring a large quantity of samples.



Incomparable speed

The CM-26dG measures color in about half the time required of previous models, at approx. 0.7 sec (SCI or SCE). Moreover, it takes about 1 sec to measure both color and gloss (SCI or SCE + Gloss). The faster measuring speed translates into higher work efficiency.




(Actual size)

Highest levels of repeatability and inter-instrument agreement amongst portable spectrophotometers

Because of the way supply chains are constantly being built and modified, data needs to be shared amongst increasingly more sites. This has made high repeatability and high inter-instrument agreement prerequisites for portable spectrophotometers. The CM-26dG and CM-26d realize the highest level of inter-instrument agreement amongst currently available portable spectrophotometers, at $\Delta E^*ab 0.12$ (BCRA average amongst 12 colors). And when measuring gloss, inter-instrument agreement of the CM-26dG is within ± 0.2 GU (0-10 GU) or ± 0.5 GU (10-100 GU). Moreover, repeatability is half that of predecessor models, at $\pm \Delta E^*ab 0.02$. The contribution to digital color data management that this level of performance offers will help manufacturers enhance quality management between their factories and suppliers.

<Quick and easy-to-use Spectrophotometer Configuration Tool CM-CT1>

The CM-CT1 gives manufacturers the means for easily and quickly setting up their CM-26dG Series spectrophotometers. Moreover, when multiple devices are used or when the same conditions need to be set amongst multiple factories or suppliers, settings can be compiled into a file and shared.



Spectrophotometer Configuration Tool CM-CT1 zOS: Windows®7 32bit, 64 bit/Windows®8.1 32bit, 64 bit/Windows®10 32bit, 64 bit
zCPU: 2 GHz equivalent or faster zMemory: 2 GB or more zHard disk: 10 GB or more of free space for installation zDisplay: Resolution: 1,024 x 720 dots or more/16-bit colors or more zOther: USB port (For connecting to spectrophotometers)

JT B USBEFNBSL PS SFHITUSFE USBEFNBSL PG - JDSPTPGU \$PSQPSBUPO JO UIF 64" BOE PUIFS DPVOUSIFT.

Highest level of repeatability with high inter-instrument agreement, incomparable speed, and high usability.

The CM-26dG Series from Konica Minolta offers three variations of advanced portable spectrophotometers.

The high-end CM-26dG and CM-26d models bring the industry's highest level of accuracy, with the CM-26dG capable of simultaneously measuring color and gloss, and the CM-26d specifically for measuring color.

The lineup is rounded out with the high cost-performance model, the CM-25d.

NEW Spectrophotometer

CM-26dG | CM-26d | CM-25d



JOB function execution screen (Actual size)

Viewfinder

The viewfinder brightly illuminates the measurement point with an LED to make target alignment faster, easier and more precise. It also incorporates a pointer that makes it even easier to identify the measurement area. Moreover, because it allows the user to look down from above the spectrophotometer, the viewfinder is perfect for setting measurement points on patterns and prints.



Compact, lightweight streamlined body

Designed to work in hard-to-reach places, the CM-26dG Series spectrophotometers allow users to take measurements where previous models could not. The nose is angled downward and rounded at the corners to get into cramped spots like dashboards at a point near the windshield. Moreover, the plastic target mask lessens the risks of scratching the sample. And there is a trigger button on both sides so that measurements can be taken stress-free in any sort of situation, no matter which hand you use.



High usability and functional versatility

<JOB Function>


Instructions (including photos) for often-used workflows can be registered using SpectraMagic NX (Ver. 2.9 or later, sold separately).

<Bluetooth® ready>

Data can be wirelessly transmitted to computers or other paired devices over a Bluetooth connection.

Color Data Software SpectraMagic NX


SpectraMagic NX is color management software that gives users a plethora of functions for viewing, operating and controlling their spectrophotometers from a computer. Users can create their own windows by arranging and editing spectral graphs, color difference graphs (2D, 3D), OK/NG indications and other objects to suit their needs.



SpectraMagic NX Ver. 2.9 or later OS: Windows® 7 Professional 32 bit, 64 bit / Windows® 8.1 Pro 32 bit, 64 bit / Windows® 10 Pro 32 bit, 64 bit
 * The computer must be running one of the above OS and meet or exceed the below specifications.
 zCPU: Pentium® III 600 MHz equivalent or faster zMemory: 128 MB or more (256 MB or more recommended) zHard disk: 450 MB or more of free space for installation zDisplay: Resolution: 1,024 x 768 dots or more / 16-bit colors or more zOther: DVD-ROM drive (for software installation), USB port (for entering the protection key), USB or serial port (for connecting to spectrophotometers) and Internet Explorer Ver. 5.01 or later installed
 tSJOEPXTY JT B USBEFNBSL PS SFHTUFSFE USBEFNBSL PG _JDSPTPGU \$PSQPSBUJPO JO UIF 64" BOE PUIFS DPVOUSIFT. t1FOUJVN Y JT B USBEFNBSL PS registered trademark of Intel Corporation in the USA and other countries.

□ **CM-26dG Series spectrophotometers can be used in a wide range of fields.**

Automotive interiors, ICT products, Home appliances, Paint, Ceramics, Plastics, Solar panels, Glass, etc.



□ **Performance by model**


	CM-26dG	CM-26d	CM-25d
SCI	z	z	z
SCE	z	z	z
60° gloss	z	—	—
MAV	z	z	z
SAV	z	z	—
UV 0% /100%	z	z	—
Inter-instrument agreement (Color)	<0.12	<0.12	<0.20
Repeatability (1σΔE*ab)	<0.02	<0.02	<0.04
Wavelength range	360 - 740 nm	360 - 740 nm	400 - 700 nm



Stapler Type Target Mask CM-A268



Target Mask (MAV; w/ glass) CM-A277





t, O/\$" - /O-5", UIF, POIDB - JOPIUB IPHP BOE TZNCPI NBSL, "CWIJOH 4IBQF UP *EFBT" BOE 4QFDUSB - BHDIM BSF SFHITUFSE USBEFNBSLT PS USBEFNBSLT PG ,O/\$" - /O-5", /\$. t#IVFUPPIIY JT B SFHITUFSE USBEFNBSL PG #IVFUPPII 4°C, *OD. BOE JT VTFE VOEFS MDFOTF BHSFFNFOL. t%ITQIBZT TIPXO BSF GPS MIVTUSBUPO QVSQPTFT POIZ. t5 IF TQFDJGDBUJ POT BOE BQQFBSBODF TIPXO IFSFJO BSF TVCIFDU UP DIBOHF XJUIPVU OPUDF.

Specifications

Model	CM-26dG	CM-26d	CM-25d
illumination/viewing system	di: 8°, de: 8° (diffuse illumination: 8° viewing) SCI (specular component included) / SCE (specular component excluded) switchable		
Integratingsphere	Ø54 mm		
Light source	Pulsed xenon lamp x2	Pulsed xenon lamp x1	
Detector	Dual 40-element silicon photodiode arrays		Dual 32-element silicon photodiode arrays
Spectral separation device	Planar diffraction grating		
Measurement wavelength range	360 to 740 nm	400 to 700 nm	
Measurement wavelength pitch	10 nm		
Half bandwidth	Approx. 10 nm		
Reflectance measurement range	0 to 175%; Display resolution: 0.01		
illumination area	12 x 12.5 mm (circle + ellipse)	MAV: Ø12mm SAV: Ø6mm	MAV : Ø12 mm
Measurement area	MAV: Ø8 mm, SAV: Ø3 mm		MAV : Ø8 mm
Repeatability	Standard deviation within ΔE*ab 0.02 (When a white calibration plate is measured 30 times at 5-second intervals after white calibration)		Standard deviation within ΔE*ab 0.04
Inter-instrument agreement	Within ΔE*ab 0.12 (Based on average for 12 BCRA Series II color tiles; MAV SCI; compared to values measured with a master body under KONICA MINOLTA standard measurement conditions)		Within ΔE*ab 0.20
UV adjustment	UV 100% / UV 0%		—
Observer	2° observer angle, 10° observer angle		
illuminant	A, C, D50, D65, F2, F6, F7, F8, F10, F11, F12, ID50, ID65, User-defined illuminant* (Simultaneous evaluation with two light sources possible)		
Display items	Colorimetric values/graph, color difference values/graph, spectral graph, pass/fail judgment, pseudocolor		
Colorimetric values	L*a*b*, L*C*h, Hunter Lab, Xyy, XYZ, and color difference in these spaces; Munsell (C)		
Indexes	MI, WI (ASTM E313-73), YI (ASTM E313-73, ASTM D1925), ISO brightness (ISO 2470), WI/Tint (CIE), Strength, Opacity, Grey scale, User index	MI, WI (ASTM E313-73), YI (ASTM E313-73, ASTM D1925), ISO brightness (ISO 2470), WI/Tint (CIE), Strength, Opacity, Grey scale, 8° gloss value, User index**	
Color difference equations	ΔE*ab (CIE1976) / ΔE94 (CIE1994) / ΔE00 (CIE2000) / CMC (l:c) / Hunter ΔE / DIN99o		
Applicable standards	DIN 5033 Teil 7, JIS Z 8722 Condition "c", ISO 7724/1, CIE No.15		
Measurement angle	60°	—	
Light source	White LED	—	
Detector	Silicon photodiode	—	
Measurement range	0 to 200 GU; Display resolution: 0.01 GU	—	
Measurement area	MAV : 10x7 mm, SAV : Ø3 mm	—	
Repeatability	Standard deviation 0 to 9.99 GU: Within 0.1 GU 10 to 99.99 GU: Within 0.2 GU 100 to 200 GU: Within 0.2% of indicated value (When measured 30 times at 5-second intervals after calibration)	—	
Inter-instrument agreement	0 to 9.99 GU: Within ±0.2 GU 10 to 99.99 GU: Within ±0.5 GU (MAV; compared to values measured with a master body under KONICA MINOLTA standard measurement conditions)	—	
Applicable standards	JIS Z8741 (MAV only), JIS K5600, ISO 2813, ISO 7668 (MAV only), ASTM D523-08, ASTM D2457-13, DIN 67530	—	
Measurement time	Approx. 1 sec. (Measurement mode: SCI + Gloss or SCE + Gloss) (From pressing trigger button to measurement completion)	Approx. 0.7 sec. (Measurement mode: SCI or SCE)	
Minimum measurement interval	Approx. 2 sec (Measurement mode: SCI + gloss or SCE + gloss)	Approx. 1.5 sec (Measurement mode: SCI or SCE)	
Data memory	1,000 target data + 5,100 sample data		
Battery performance	Measurement mode: SCI + Gloss or SCE + Gloss Approx. 3,000 measurements (approx. 1,000 measurements when using Bluetooth) when measurements are taken at 10-second intervals at 23°C with the dedicated lithium battery		
Viewfinder function	Available (with white LED illumination)		
Display	2.7" color TFT-LCD with reversible portrait viewing mode		
Display language	English, Japanese, German, French, Italian, Spanish, Simplified Chinese, Portuguese, Russian, Turkish, Polish		
Interface	USB 2.0; Bluetooth (SPP-compatible). Optional Bluetooth module required		
Power	Dedicated lithium-ion battery (removable), USB bus power (with lithium-ion battery installed), Dedicated AC adapter (with lithium-ion battery installed)		
Charging time	Approx. 6 h		
Operating temperature/humidity range	Temperature: 5 to 40°C, Relative humidity: 80% or less (at 35°C) with no condensation		
Storage temperature/humidity range	Temperature: 0 to 45°C, Relative humidity: 80% or less (at 35°C) with no condensation		
Size	Approx. 81 (W) x 93 (H) x 229 (D) mm		
Weight	Approx. 660 g	Approx. 630 g	Approx. 620 g

*1 Optional Color Management Software SpectraMagic NX is required for setting user-configured illuminants or user indexes.

System Diagram



* Depending on the location, some accessories may not be available.
** May be included as a standard accessory in some regions.



Extralab Brasil Com. e Manut. de Equip. para Lab. Ltda.
Rua Benjamin Constant, 501 - Ed. Office Center - Itatiba, SP - 13.250-340
Unidade I - Térreo | Adm/Financ/Coml
Unidade II - 9º andar | Assist. Técnica/Engenharia
www.extralab.com.br ☎ (11) 4524-2414



SAFETY PRECAUTIONS

For correct use and for your safety, be sure to read the instruction manual before using the instrument.

- Always connect the instrument to the specified power supply voltage. Improper connection may cause a fire or electric shock.

ISO Certifications of KONICA MINOLTA, Inc., Sakai Site



JQA-QMA15888 Design, development, manufacture/ manufacturing management, calibration, and manufacture, service and sales of measuring instruments
JQA-E-80027 Design, development, manufacture, service and sales of measuring instruments

KONICA MINOLTA, INC.
Konica Minolta Sensing Americas, Inc.
Konica Minolta Sensing Europe B.V.

Osaka, Japan
New Jersey, U.S.A.
European Headquarter / BENELUX
German Office
French Office
UK Office
Italian Office
Swiss Office
Nordic Office
Polish Office
Turkish Office
SE Sales Division
Beijing Office
Guangzhou Office
Chongqing Office
Qingdao Office
Wuhan Office

Phone : 888-473-2656 (in USA), 201-236-4300 (outside USA)
Nieuwegein, Netherlands
München, Germany
Roissy CDG, France
Warrington, United Kingdom
Cinisello Balsamo, Italy
Dietikon, Switzerland
Västra Frölunda, Sweden
Wroclaw, Poland
Istanbul, Turkey
Shanghai, China
Beijing, China
Guangdong, China
Chongqing, China
Shandong, China
Hubei, China
Singapore
Goyang-si, Korea

Fax : 201-785-2482
+31 (0) 30 24 81 211
+49 (0) 89 4357 156 99
+33 (0) 1 80 11 10 82
+44 (0) 1925 711143
+39 02849488.00
+41 (0) 43 322-9800
+48 (0) 71 73452-11
+90 (0) 216-528 56 56
+86- (0)21-5489 0202
+86- (0)10-8522 1551
+86- (0)20-3826 4220
+86- (0)23-6773 4988
+86- (0)532-8079 1871
+86- (0)27-8544 9942
+65 6563-5533
+82 (0) 2-523-9726

Konica Minolta (CHINA) Investment Ltd.

Konica Minolta Sensing Singapore Pte Ltd.
Konica Minolta Sensing Korea Co., Ltd.

Addresses and telephone/fax numbers are subject to change without notice. For the latest contact information, please refer to the KONICA MINOLTA Worldwide Offices web page :

©2019 KONICAMINOLTA, INC.

<https://konicaminolta.com/instruments/network>

9242-AC5J-41 BJCPK1